

## Battery change procedure (Non-monitored Systems only)

As all reputable security company's we highly recommend you allow us to replace your batteries as by doing so, a full check can be carried out at the end. However, should you choose to replace the Batteries yourself, the following is a brief 'How to Guide'.

### Risco Agility Smart Video Wireless Alarm System



1. Remove the Detector from its installed location

**The Alarm will sound locally as in Tamper.**

2. Press the UNSET Button
3. Enter your 4 digit User Code

**The Alarm will display the Detector currently in Tamper.**

4. Remove the Battery compartment cover or Backplate to expose the Battery(s)
5. Replace the Battery(s) with brand new CR2 & AA Duracell Alkaline type batteries
6. Replace the Battery Compartment Cover or Backplate
7. Return the Detector back to its installed location

**Now do this for the remaining Detectors. Once all batteries have been changed:**

8. Press the UNSET Button
9. Enter your 4 digit User Code

**The display should now read Platinum Security.**



### Scantronic ION16/30 Wireless Alarm System



1. Remove the Detector from its installed location

**The Alarm will sound locally as in Tamper and a Red Square will be displayed.**

2. Enter your 4 digit User Code to silence alarm

**The Alarm will display the Detector currently in Tamper and display a Red Square.**

3. Remove the Battery compartment cover or Backplate to expose the Battery(s)
4. Replace the Battery(s) with brand new CR123 Lithium type batteries
5. Replace the Battery Compartment Cover or Backplate
6. Return the Detector back to its installed location

**Now do this for the remaining Detectors. Once all batteries have been changed:**

7. Enter your 4 digit User Code followed by X

**The display should now read Time & Date with a Green Square displayed.**



### Visionic Powermax Wireless Alarm System



1. Remove the Detector from its installed location and open it to expose the Battery.

**The Alarm will sound and display 'Trouble'. Flip down the front cover.**

2. Press the 'Off' button (it has a padlock printed on the top). 'Code' will appear.
3. Enter your 4 digit **User Code**

4. Remove the Battery compartment cover or Backplate to expose the Battery(s)
5. Replace the Battery(s) with branded CR123 3V batteries
6. Replace the Battery Compartment Cover or Backplate
7. Return the Detector back to its installed location

8. Press the 'Off' button (it has a padlock printed on the top). 'Code' will appear.

9. Enter your 4 digit **User Code**

**The panel will bleep to confirm it has reset and display the current time & date.**



Platinum Security Ltd, 125 Albany Road, Hornchurch, Essex RM12 4AQ  
Tel: 01708 733264 / 744868 email: office@platinumsec.co.uk

[www.platinumsec.co.uk](http://www.platinumsec.co.uk)



Download our **FREE** App  
now from your App Store  
Search 'Platinum Security'

